


English

Building & Industry



NOVenco® Nova™

Fan heaters type VMA-VMB

Installation and maintenance

Novenco® NoVa™ air heaters type VMA and VMB

Installation and maintenance

Contents

1. Application

1.1 Reading guide

2. Product overview

2.1 Scope of delivery

2.2 Mounting positions

2.3 Storage

3. Installation

3.1 Assembly and mounting

3.2 Pipe circuit construction

3.3 Connection of heating medium

3.4 Regulation and frost protection

3.5 Electrical connections

4. Maintenance

4.1 Inspection

4.2 Cleaning

4.3 Impeller

4.4 Motor

4.5 Heating coil

4.6 Damper

4.7 Filters

4.8 Other components

5. Electrical connection

5.1 Motors

5.2 Regulators

5.3 Re-configuration of NV515 – 5-step

5.4 Wiring diagrams

6. Troubleshooting

7. Inspection and test

8. Sound

9. Safety

10. Disposal

11. Intellectual property rights

12. Quality management

13. Warranty

14. Spare parts

15. Product lifetime

16. Other applied standards

17. Declaration of conformity

Appendices – wiring diagrams

A. Thermostats RDG100T and NV515

B. RDG100T – 5-step regulators

- C. RDG100T – stepless regulator 2.5 A
- D. RDG100T – stepless regulator 5 A
- E. NV515 – 5-step regulators
- F. NV515 – stepless regulator 2.5 A
- G. NV515 – stepless regulator 5 A

1. Application

The Novenco NoVa air heaters type VMA and VMB are for heating of industrial work zones, workshops, halls, warehouses, sports centres etc.

1.1 Reading guide

Please read this complete guide, before beginning installation or maintenance.

Icons	Description
	Risk of damage to equipment
	Risk of injury or death

Table 1. Icons in guide

2. Product overview

The air heater consists of a basic unit, which can be fitted with accessories for air distribution on the outlet side.

Legend for figure 1

- 1. Fan suspension
- 2. Motor and fan
- 3. Heating coil
- 4. Cabinet
- 5. Mounting and wire guard brackets
- 6. Supply water
- 7. Return water




Figure 1. Basic unit

Legend for figures 2 and 3

- 1. Basic unit with fan and heating coil
- 2. Front grille J1 - with individually adjustable-louvres
- 3. Front grille J2 - with adjustable louvres in two directions
- 4. Air diffuser J4 - for horizontal air distribution in four directions with vertical supply
- 5. Air cone K - for jet-shaped air distribution in high-ceiling rooms.




Figure 2. Horizontal position




Figure 3. Vertical position

The basic unit is a cabinet with heating coil and an axial fan. The fan motor is on the inlet side. Pipe connections for the heating medium are on the cabinet side.

The fan motor has a 1.5 m cable.

The VMA is for water from boilers or heat pumps with temperature drops of 10 to 20 °C.

The VMB is for water from district-heating systems with temperature

drops of 40 °C.

Refer to the technical calculation.

2.1 Scope of delivery

The basic unit and accessories are delivered in cartons. Ducting is outside the scope of delivery.

Included with the basic unit

- 2 mounting brackets for installations without accessories on the inlet side
- A drilling template for mounting brackets
- Self-tapping screws for mounting of accessories on the outlet side

Types	Weights [kg]
VMA/B 42-43	20
VMA/B 52-53	30
VMA/B 62-63	40
VMA/B 72-73	50
VMA/B 82-84	67

Table 2. Maximum base weights

2.2 Mounting positions

The units are for wall or ceiling mounting for horizontal or vertical air distribution, respectively. Water pipe connections are on the side.

2.3 Storage

Correct storage is important for the function and durability of the fans.



Damages due to incorrect storage void the warranty.

Condition	Specification	Comments
Outdoor	One month	<ul style="list-style-type: none"> • Packaging must be intact
Indoor or sheltered	Max. six months	<ul style="list-style-type: none"> • For unprotected fans with no or broken packaging • Ventilated location • No condensation
Prolonged	Max. two years	<ul style="list-style-type: none"> • Indoor • Remove packaging • Ventilated location • No condensation • Turn impeller <p>20 times every six months</p> <ul style="list-style-type: none"> • Add additional anti-corrosive coating on motor shaft • Change motor ball bearings after two years of storage

Table 3. Storage recommendations

Condition	Specification	Comments
Vibrations	No	<ul style="list-style-type: none"> • Location must be vibration free
Temperatures	-20 to 55 °C	<ul style="list-style-type: none"> • Constant temperature, preferably 20 °C • Ventilated • No condensation
Humidity	Below 70%	<ul style="list-style-type: none"> • Avoid condensation • Exceedance requires airtight packaging of complete fan and use of a moisture absorbent agent such as silica gel

Table 3. Storage recommendations

3. Installation

3.1 Assembly and mounting

Mount air distribution accessories with the supplied screws onto the outlet, before mounting the unit. The natural frequency of the surface the fans are mounted onto must be 20% higher than the fan speed.

Types	Frequency [Hz]	RPMs
VMA/B 42-43	50 / 60	1350 / 1490
VMA/B 52-53	50 / -	1300 / -
VMA/B 62-63		1320 / 1450
VMA/B 72-73	50 / 60	910 / 980
VMA/B 82-84		920 / 1080

Table 4. Fan RPMs

1. Screw the mounting brackets onto the basic unit.

Eight screws are included. Position of brackets is identical for wall and ceiling mounts.




Figure 4. Installation – wall

2. Mark holes for mounting on the wall or ceiling surfaces using the included template sheet.

Note: The underside of wall-mounted units must be at least 2.2 m above the floor.

3. Drill holes for M8 size bolts.




Figure 5. Installation – ceiling

4. Lift the unit into position and support it.

M8 lifting eyes can be placed in the mounting brackets.




Figure 6. Hoisting

5. Tighten the fastening bolts and screws carefully.

For non-supporting ceilings M8 threaded rods with discs and nuts can be used for suspension in sectional frames attached to supporting parts. See figure 5, type B.

3.2 Pipe circuit construction




Figure 7. Basic system layout – pipe circuit and electric wiring

Review the basic system layout in figure 7. It shows the principle, which the implemented system should follow.

It is recommended to make a plan of both the pipe and the electrical circuits.

Construction stages

1. Connect the air heaters and flow valves to the heating medium as described in section "3.3 Connection of heating medium".
2. Connect the regulation and frost protection. See section "3.4 Regulation and frost protection".
3. Connect the electrical as described in section "3.5 Electrical connections".
4. Test the system.

3.3 Connection of heating medium

The air heaters are designed for hot water as heating medium.

Heating media sources

- Boilers – type VMA
- Heat pumps – type VMA
- District heating – type VMB

Pipe connections are 5/4" pipe thread. The water flow direction is indicated on the pipe connections.

! The supply water connector is the one close to the front of the air heater. See figure 7.

Check the orientation of the flow valves and set the maximum water flow rate. The flow rate can be calculated with the following formula.

$$Q_{\text{water}} = \frac{P}{\frac{\Delta_{\text{loss}}}{10 \text{ } ^\circ\text{C}}} \times 3600 \times 42$$

Example

Heat need: 50 kW
Heat loss: 20 °C
No. of heaters: 3

$$Q_{\text{water}} = \frac{\frac{50}{3}}{\frac{20}{10} \times 42} \times 3600$$

$$Q_{\text{water}} = 714 \text{ l/h}$$

After installation and connection of pipes and valves, thoroughly dry all surfaces to remove moisture that could be mistaken as leakage. Install f.x. also pipe insulation sleeves on the supply and return pipes to avoid condensation, which might resemble a leak.

3.4 Regulation and frost protection

Regulation of the heat supply is done by changing the fan speed. See section "3.5 Electrical connections". In addition, the water flow in the heating coil should be constant for regulation through changing of the water temperature.




Figure 8. Constant flow in coil

Fans with fresh air supply must be protected against frost. When using water as heating medium an

! The pipe circuit must be made according to current regulations and by authorised personnel.

automatic control system with a frost indicator should be installed. The preferred method is with a stem bulb sensor in the return water. At low temperatures this stops the fan, closes the damper against the outside air and ensures full flow in the automatic regulator valve.

3.5 Electrical connections

 The electrical connections must be made according to current regulations and by authorised personnel.

Connect the motors to the electrical supply.

The fans can be connected to different types of speed regulators. See the wiring diagrams on pages 10 to 13.

After connecting the motor, check the direction of rotation from the fan inlet side.

Directions of rotation

- VM-4 and -5: Counter-clockwise
- VM-6, -7 and -8: Clockwise

Access to the fan motor on units with mixing housings is typically done by removing a side plate opposite the damper shaft.

The damper motor has a terminal box for direct cable connection.

4. Maintenance

The air heaters are designed to give long and reliable operation and to require little service.

 The electric system must be switched off and locked to avoid unintentional starts when maintenance is performed.

The air heaters must be kept clean at all times for optimum performance and best level of comfort. Inspect and clean the units as needed. Units installed in dust-filled environments require more frequent maintenance.

Refer to figure 1. Basic unit in the following sections.

4.1 Inspection

Air heaters without accessories on the inlet side can be checked directly.

Inspection of the inlet on units with mixing housings is typically done by removing a vertical side plate of the mixing housing opposite to the damper shaft.

4.2 Cleaning

Dust builds up inside the unit cabinets and reduce the performance if not removed.

Build-ups on fan suspensions, wire guards, heating coils and dampers can usually be removed by vacuum cleaning. Cleaning the inlet of the heating coil can be done after removing the fan unit with suspension. See section "4.4 Motor".

On the outlet side it is possible to remove the front grille.

Wall grilles for fresh air and wire guards for return air ducts must also be kept free from dust and foreign particles.

4.3 Impeller

The fan unit has been carefully balanced. If vibrations occur during operation, it may be due to dust on the fan blades. If vibrations persist after cleaning; stop the unit and call for skilled assistance. Continued operation with vibrations damages the motor bearings.

4.4 Motor

The motor and impeller is a one piece assembly. The motor bearings are greased for life, i.e. approx. 30.000 working hours and cannot be greased anew. When the service life of the bearings has run out, they should be replaced. Replacement of the bearings should be carried out by a specialist. During replacement, remove the entire unit comprising fan suspension and fan. Afterwards, remove the suspension from the fan. When re-mounting, the fan must be centred carefully with equal blade clearance around the circumference.

4.5 Heating coil

The heating coil has copper tubes with aluminium fins and is sensitive to frost. If there is a risk of hard frost, it might be necessary – besides the established frost protection at the fresh air inlet – to empty the heating coil of water. In exposed installations it is recommended to supply the plant with antifreeze.

4.6 Damper

The damper function should be checked on occasion.

4.7 Filters

Filters from Novenco are made of synthetic material and must be cleaned occasionally to maintain fan performance. Cleaning is done either by vacuum cleaning the dirty side of the filter mat, rinsing from the clean side or by washing in lukewarm soap water at max. 40 °C. The filter mat can be washed four times, before it must be replaced. During cleaning or replacement of the filter, draw out the filter cassette and insert a new filter after cleaning the mat retainers. The filter cassette is fitted with a handle. The retainers are of Velcro and reusable.

When ordering a new filter mat, observe the type and size of fan, e.g. VMA-62.

The filter condition must be checked 2 weeks after start-up of the fan and then once every month.

Recommended rise in differential pressure above the filter mat is 100 Pa.

4.8 Other components

Components for regulation, ventilation, water outlet and other accessories essential for the correct operation of the fan, need regular inspection and maintenance according to the manufacturer's instructions.

5. Electrical connection

	The installation and connection to the supply network must be done by authorised personnel and according to current legislation, e.g. the EU standard for electromagnetic compatibility (EMC).
---	--

5.1 Motors

All motors are 1x230 V.

Sizes	Frequency [Hz]	RPMs	Power [W]	Current [A]
4-	50 / 60	1350 / 1490	110 / 148	0.52 / 0.66
5-	50 / -	1300 / -	190 / -	0.66 / -
6-		1320 / 1450	410 / 570	1.90 / 2.50
7-	50 / 60	910 / 980	390 / 580	1.80 / 2.60
8-		920 / 1080	470 / 730	2.30 / 3.20

Sizes	Starting current [A]	Ambient temp. ranges [°C]	Weight [kg]	Encapsulation
4-	1.20 / 1.18	-20 to 45	3.5	IP44
5-	-	-	-	
6-	4.40 / -	-15 to 60	9.2	
7-	-	-	-	IP54
8-	5.50 / -	-15 to 45	12.8	

Table 5. Motor specifications¹

1.The motors comply with EU's ErP 2015 directive.

5.2 Regulators

When in operation, the 2.5 A and 5 A stepless TRIAC regulators generate audible noise.

Types	Regulation type	Voltage [V]	Max. current [A]	Encapsulation
RDG100T	Thermo-stat	1x230	4	IP30
			6	IP34
5-step	Speed		1.5	
			3.5	
Stepless			5	IP54
			10	
			2.5	
			5	

Types	Max. current [A]	h [mm]	w [mm]	d [mm]	Weight [kg]
RDG100T	4	128	93	30.8	0.3
NV515	6	-	-	-	-

Table 6. Regulator specifications

Types	Max. current [A]	h [mm]	w [mm]	d [mm]	Weight [kg]
5-step	1.5	205	115	100	2.1
	3.5	255	170	140	5.0
	5	255	170	140	5.4
	10	325	300	185	13.2
Stepless	2.5	82	82	65	0.24
	5	160	83	81	0.59

Table 6. Regulator specifications

 The fan speed control wires must only be moved between the seven regulated output voltage positions. It is recommended to keep the colour order of the wires and to leave the blue wire at 0 V, which is Off for knob position 0.

4. Remount the front cover.
5. Connect power to the regulator.

Connection of external device for knob position 0

The NV515 – 5-step regulator has an unregulated output on the connectors N1 and L1. These are active for knob position 0 and can be used to trigger an LED, a valve, a motor etc. See figures 13 and 14 (right) on page 12.

1. Disconnect power for the regulator.
2. Remove the front cover.
3. Connect external device to the connectors N1 and L1.
4. Remount the front cover.
5. Reconnect power for regulator.

5.4 Wiring diagrams

The fan motors are connected through a voltage regulator. See the appendices for wiring diagrams of how to connect the thermostats and how to connect the thermostats with the regulators.

Several fan motors can be connected in parallel to the same regulator. See table 7. "Max. number of motors per regulator at 50 / 60 Hz".

6. Troubleshooting

In case of breakdowns, the following checklists should be completed, before calling for service.

Lacking performance

- Damper closed
- Ducts clogged
- Supply fan stopped
- Motor defective
- Motor disconnected
- Wrong direction of rotation

Noise and vibrations

- Motor bearings defective
- Impeller out of balance
- Impeller worn or damaged
- Bolts or components loose

Fans operating in the stalling area, may result in breakdowns.

7. Inspection and test

It is recommended to test and inspect the air heaters at regular intervals with regard to operability and operating conditions.

Extent of inspection

- Measure power consumption
- Check torques for fixing bolts and correct if necessary
- Cleaning
- Visual inspection of cabinet, pipe and electric connections

Enter all values and observations in a log.

8. Sound

Sizes	RPMs	Sound power Level total [dB]	Sound pressure level [dB(A)] ¹
4-	1350	59	45
5-	1300	—	—
6-	1400	74	60
7-	910	71	57
8-	950	76	62

Table 8. Sound data, VMA and VMB without accessories

1.Sound pressure level at a distance of 5 m, room of 1,500 m³, normal reflection, direction factor Q = 2

9. Safety

The air heaters must be installed according to Novenco', the current and the local safety regulations. At a minimum these include EN 13850. It is recommended to review and revise safety procedures regularly.

Safety check

- Test if safety procedures and the installation work correctly.
- Check if safety regulations have been changed and if the installation needs revising.
- Consider taking additional

measures to improve the safety of the installation.

10. Disposal

Dispose of air heaters suitable for scrapping in environmentally safe ways and in accordance to current regulations.

The air heaters and especially the electric motors contain recyclable materials. Make sure worn-out motors and fan parts are disassembled and recycled for the benefit of the environment

11. Intellectual property rights

Novenco®, ZerAx®, 诺文科, 诺万科 and 诺克 are registered trademarks of Novenco Marine & Offshore A/S. ZerAx® is a registered trademark of Novenco Building & Industry A/S. AirBox™, NoVa™ and NovAx™ are trademarks of Novenco Building & Industry A/S.

Other trademarks that appear in this document are the property of their respective owners.

This guide is copyright © 2003 - 2025, Novenco Building & Industry A/S. All rights are reserved.

12. Quality management

Novenco is ISO 9001 certified. This means that all air heaters are inspected and tested, before leaving the production.

13. Warranty

Novenco provides according to law a standard 12 months warranty from the product is sent from the factory. The warranty covers materials and manufacturing defects. Wear parts are not covered.

Extended warranty can be agreed upon.

14. Spare parts

Contact Novenco for information about and ordering of spare parts.

15. Product lifetime

The air heaters have a product lifetime of 20 years. Storage, installation and maintenance must

be in accordance with Novenco's instructions, which include this installation and maintenance guide.

16. Other applied standards

In addition to the standards mentioned in the Declaration of conformity, relevant parts of the following standards have also been applied.

- EN 5801:2017+A1:2025
- EN 10346:2015
- EN 12499:2009
- EN 12944-2:2017
- EN 13349:2010
- ISO 14694:2003+A1:2010
- ISO 14695:2003+Corr1:2009
- ISO 21940-1:2019
- ISO 21940-11:2016+A1:2022
- ISO 21940-14:2012
- ISO 21940-32:2012

17. Declaration of conformity

Novenco Building & Industry A/S
 Oeverup Erhvervsvej 50-52
 4700 Naestved
 Denmark

hereby declares that the air heaters type VMA and VMB have been manufactured in accordance to below legislation of the European Council and of the United Kingdom.

EU directives and regulations

- CPR 305/2011
- Ecodesign 2019/1781
- EMC 2014/30
- LVD 2014/35
- Machinery 2006/42

UK regulations

- Construction Products 2013/1387
- Electrical Equipment (Safety) 2016/1101
- Electromagnetic Compatibility 2016/1091
- Supply of Machinery (Safety) 2008/1597

Relevant parts of the following harmonised standards have been applied.

- EN 12100:2011
- EN 13857:2019
- EN 60034-1:2010
- EN 60204-1:2018+A1:2020
- EN 61000-6-1:2007
- EN 61000-6-2:2005+Corr:2005
- EN 61000-6-3:2007+A1:2011
- EN 61000-6-4:2007+A1:2011
- EN 61800-3:2005+A1:2012


It is conditioned for the validity of the warranty that Novenco' instructions for installation and maintenance have been followed.

UK representative

Novenco Building & Industry UK, Ltd
 2A Halifax Road
 Bowerhill
 Wiltshire
 SN12 6YY
 United Kingdom

Phone: +44 800 681 60 09
 E-mail:
info-uk@novenco-building.com

Signed for and on behalf of
 Naestved, Denmark, 1st June 2025



Peter Holt
 Technical director
 Novenco Building & Industry A/S



Appendices – wiring diagrams

A. Thermostats RDG100T and NV515




Figure 9. Wiring diagrams for RDG100T and NV515 thermostats

B. RDG100T – 5-step regulators




Figure 10. Wiring diagram for RDG100T and 5-step regulators 1.5 A, 3.5 A, 5 A and 10 A

C. RDG100T – stepless regulator 2.5 A




Figure 11. Wiring diagram for RDG100T and stepless regulator 2.5 A

D. RDG100T – stepless regulator 5 A




Figure 12. Wiring diagram for RDG100T and stepless regulator 5 A

E. NV515 – 5-step regulators




Figure 13. Wiring diagram for NV515 and 5-step regulators 1.5 A, 3.5 A, 5 A and 10 A

Default		Re-connect example				
Knob positions	Coloured wires	Knob positions	Coloured wires	Regulated output voltages [VAC]	Fan speeds associated with output voltages	
0	Blue	0	Blue	0	Off	
---	---	1	Grey	80	Minimum	
1	Grey	2	Purple	110	Slow	
2	Purple	3	Orange	140	Medium	
3	Orange	4	Brown	170	Moderate	
4	Brown	---	---	190	Fast	
5	Red	5	Red	230	Maximum	

Table 9. Default and re-connect settings for NV515 – 5-step regulators




Figure 14. NV515 – 5-step regulator, minimum fan speed enabled (left) and location of N1 and L1 connectors (right)

F. NV515 – stepless regulator 2.5 A




Figure 15. Wiring diagram for NV515 and stepless regulator 2.5 A

G. NV515 – stepless regulator 5 A





Figure 16. Wiring diagram for NV515 and stepless regulator 5 A



info@novenco-building.com

+45 70 77 88 99

novenco-building.com